



LITTLE NATION

KID'S WOODEN TREE SWING

INSTRUCTION MANUAL

UK
CA





WARNINGS & SPECIFICATIONS

- Minimum User Age: Over 3 years old.
 - Maximum User Weight: 220 pounds.
 - The toy is suitable for both indoor and outdoor use.
 - Only for domestic use.
- Long ropes pose a risk of suffocation, and this product is prohibited for children aged 0-3 years old to use.

ASSEMBLY INSTRUCTIONS

1. Please keep the assembly and installation instructions for further reference.

An adult should supervise play on this product for children of all ages.

2. It is recommended to place activity toys on a horizontal surface at least 2 meters away from any building or obstacle, such as fences, garages, houses, hanging branches, laundry lines, or electrical wires.

3. When used outdoors, you should ensure that the swing frame is stably welded to the ground to prevent the frame from tipping over due to excessive swing amplitude. When using indoors, make sure your anchor point is perpendicular to the ground.

4. A certain height needs to be maintained between the swing and the ground, which is approximately greater than 30cm plus the length of the calf.

5. Swing should not be used on hard surfaces such as concrete, asphalt, or any other hard surfaces.

6. When using outdoors, it is recommended to turn your back to sunlight to reduce the damage of ultraviolet rays to your eyes.

7. Limit: 1 child per swing.

8. Children should be dressed appropriately including wearing well-fitting shoes that fully protect feet. Remove articles before swinging that create hazards when they get tangled and caught (examples include: ponchos, scarves, and other loose-fitting clothing).

9. Instruct children:

- Not to swing higher than hook attachment.
- Get off swing only after it has completely stopped and hold onto the rope or chain until both feet are planted firmly on the ground.
- Not to twist swing chains or ropes or loop them over the top support bar since this may reduce the strength of the chain or rope.
- Not to walk close to, in front of, or behind, or between moving items.
- Not to use the equipment in a manner other than intended.
- Not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.

To remove their other sports helmet before playing on the playground equipment.

Do not use swing when it is wet, to prevent children from slipping.

10. You should follow our usage recommendations. Otherwise, you may be at risk of injury.

HOW TO USE THE SWING



STEP 1

Fix the iron rings on the swing rope to the suspension point, such as the anchor point on the roof, tree trunk, swing frame, etc.



STEP 2

Fix the iron rings on the swing rope to the suspension point, such as the anchor point on the roof, tree trunk, swing frame, etc.



STEP 3

Fix the iron rings on the swing rope to the suspension point, such as the anchor point on the roof, tree trunk, swing frame, etc.



STEP 4

Fix the iron rings on the swing rope to the suspension point, such as the anchor point on the roof, tree trunk, swing frame, etc.

